



# Installation Instructions

## CP-PG-BLK-N4 or CP-PG-SS-N4X


### Cover Plate with PermaGland Cable Exit

#### → IMPORTANT!


FOLLOW THESE INSTRUCTIONS CAREFULLY IN ORDER TO GET A WATERTIGHT NEMA 12/4/4X SEAL. FAILURE TO FOLLOW THESE INSTRUCTIONS COULD VOID THE WARRANTY IF WATER DAMAGE OCCURS.

1. Connect all cables to the monitor. Secure cables by completely turning all strain relief screw locks. Use the USB strain relief clip to secure USB cables.

**NOTE: Cables for the CP-PG series cover plates are shipped already installed in the cover plate.**



2. Position the cover plate on the rear cover with cables pointing towards the center of the monitor.



3. Install the provided eight sealing screws and tighten evenly until the gasket on the cover plate is 1/16" to 3/32" thick.

